

HOW TO ASSEMBLE FLUSH SIDES

1. Before fastening the FRONT FRAME to the cabinet SIDES, place a small bead of glue in the outside flush side groove. This will help hold this joint tight after the assembly is finished.
2. After assembly is completed, use bar clamps to be sure the FRONT FRAME is pulled tight against the FLUSH SIDES.

*NOTE: The design of the FLUSH SIDES will allow approximately a 1/16" offset between the SIDES and the FRONT FRAME. To make a completely flush side, trim the offset with a flush trim router bit and a sander before finishing.

