

## LETTER FILE SLOT

1. Insert a small amount of glue into each construction hole. (Do not put glue between holes) The amount of glue is critical to making a well constructed cabinet. Too much glue will prevent the joints from closing...insufficient glue will affect the cabinet stability.
2. Mount DIVIDERS and SHELVES onto TOP and BOTTOM. Slide BACK in groove in TOP and BOTTOM. Attach SIDES.
3. Pin BACK into DIVIDERS for added stability.

