

## WALL OPEN SHELF

1. Insert a small amount of glue into each 8 mm construction hole. (Do not put glue between holes)  
The amount of glue is critical to making a well constructed cabinet. Too much glue will prevent the joints from closing.....insufficient glue will affect the cabinet stability. Insert the SHELVES into the cabinet BACK. Position the cabinet SIDE with the SHELVES and cabinet BACK. Using a rubber mallet, tap all pieces together to assure proper construction.

Note: Fill construction holes approximately 1/4 full of glue.

